

7010

EMI Receiver with built-in LISN



Main Features

- 7010 Opt.00: 150 kHz to 1 GHz frequency range
- 7010 Opt.01: 9 kHz to 1 GHz frequency range
- 7010 Opt.02: 9 kHz to 30 MHz frequency range
- 7010 Opt.03: 9 kHz to 3 GHz frequency range
- Built to CISPR 16-1-1 and to CISPR 16-1-2 Standards
- Conducted and radiated emission tests
- Built-in 16 A two Lines Impedance Stabilization Network (LISN)
- User Port for driving external LISNs
- Free PES PMM Emission Suite Software with Smart Detector function (*)
- Combination of EMI test receiver and spectrum analyzer
- Direct Analog to Digital conversion up to 30 MHz
- Robust, compact construction
- 140 dB μ V (2 W) maximum input level without damage

7010 EMI Receiver is an easy-to-use, very flexible equipment suitable for conducted and radiated measurements from 9 kHz up to 3 GHz. Thanks to its built-in 16 A Line Impedance Stabilization Network (LISN), 7010 allows complete conducted emission measurements and characterization of EUTs with no external or additional equipment. The compact and rugged construction makes the 7010 a perfect companion on the workbench of products designers, for in-site testing, and for laboratory prequalification EMI emission measurements.

Based on innovative design, the 7010 EMI Receiver combines state of art digital technology with a RF front-end as required by CISPR standards, thus matching excellent accuracy with high flexibility.

The PMM Emission Suite software features a full set of user-friendly functions for all EMI applications.

The receiver can be ordered with four different frequency ranges: 150 kHz to 1 GHz (7010 opt.00), 9 kHz to 1 GHz (7010 opt.01), 9 kHz to 30 MHz (7010 opt.02) and 9 kHz to 3 GHz (7010 opt.03). The upgrade from one version to another can be done at any time.

(*) The Smart Detector is an innovative special function implemented in the PMM receivers with the purpose of reducing the test time and increasing the productivity of the lab.

7010

EMI Receiver with built-in LISN

SPECIFICATIONS

Frequency range	150 kHz to 1 GHz (Opt.00) 9 kHz to 1 GHz (Opt.01) 9 kHz to 30 MHz (Opt.02) 9 kHz to 3 GHz (Opt.03)		
Resolution	10 Hz		
Frequency accuracy	< 3 ppm		
RF Input	Zin 50 Ω, N fem.		
VSWR	< 1,2; < 2 over 1 GHz		
Attenuator	0 dB to 35 dB (5dB steps) 0 dB to 50 dB (2dB steps) over 30 MHz Built-in up to 30 MHz		
Pulse Limiter			
Max input level (without equipment damage)	140 dBμV (2 W)		
Sinewave AC Voltage	100 dBμV/MHz		
Preselector (Permanent built-in)	9 kHz to 30 MHz 30 MHz to 1 GHz 1 GHz to 3 GHz		
IF bandwidth			
6dB bandwidth	1 (Opt.01, 02 & 03), 3, 10, 30, 100, 300 kHz, 1 MHz (Opt.03)		
CISPR 16-1-1	200 Hz (Opt.01, 02 & 03), 9 kHz and 120 kHz		
Noise level (Att 0 dB, 50 Ω term, Hold time 1 s)	0,009 to 0,15 MHz (200 Hz RBW)	< 0 dBμV (QP) (-130 dBm/Hz);	< -3 dBμV (AV) (-133 dBm/Hz)
	0,15 to 30 MHz (9 kHz RBW)	< 14 dBμV (QP) (-128 dBm/Hz);	< 7 dBμV (AV) (-135 dBm/Hz)
	30 to 1000 MHz (120 kHz RBW)	< 14 dBμV (QP) (-144 dBm/Hz);	< 7 dBμV (AV) (-151 dBm/Hz)
	1000 to 2700 MHz (1 MHz RBW)	< 16 dBμV (AV) (-151 dBm/Hz)	
	2700 to 3000 MHz (1 MHz RBW)	< 19 dBμV (AV) (-148 dBm/Hz)	
Spurious response (Att 0 dB, 50 Ω term, det. PK, Hold time 10 ms)	< 20 dBμV; < 23 dBμV over 2700 MHz		
Detectors	Peak, Quasi-Peak, Average, RMS, RMS-Avg (optional), C-Avg, Smart Detector function		
Level measuring time (hold time)	0,2 ms to 120 s (CISPR 16-1-1 as default)		
Measurement accuracy S/N > 20 dB	9 kHz to 1 GHz ± 1,0 dB 1 GHz to 3 GHz ± 1,5 dB		
Main measuring functions (With included PMM Emission Suite SW)	<ul style="list-style-type: none"> • Marker, marker peak, marker to centre, highest peaks, move peak to Analyzer or Manual modes, automatic test report. • 80 to 200 dB selectable dynamic range. • Display unit: dBm, dBμV, dBμA, dBμV/m, dBpT, dBμA/m, dBpW. • Store-Load: traces, panels, conversion factors, limits. 		
CISPR 16-1-1 conformity	Standard compliant detectors down to 20 Hz PRF		
Demodulation	Built-in AM and FM demodulators (internal loudspeaker)		
I/O Interface (protocol available for software developers)	USB 2.0; RS-232; User Port (drives LISNs and accessories)		
Operating temperature	-5° to 45°C		
Power Supply	12 Volt DC, 0.8A (AC universal adapter)		
Built-in LISN (compliant to CISPR 16-1-2)			
Frequency range	9 kHz to 30 MHz		
Continuous rated output current	16A		
Max permissible operating voltage	250 Vac – 350 Vdc		
EUT Supply frequency range	DC to 60 Hz		
CISPR equivalent circuit	50 Ω // (5 Ω + 50 μH)		
EUT Power connector	Schuko 2P+E		
Artificial Hand	4 mm socket		
Dimensions	235 x 105 x 335 mm		
Weight	5,0 kg		



Ordering Information:

- 7010 Option 00 (150 kHz to 1 GHz)
- 7010 Option 01 (9 kHz to 1 GHz)
- 7010 Option 02 (9 kHz to 30 MHz)
- 7010 Option 03 (9 kHz to 3 GHz)

Includes: LISN mains cable, RS232 cable, USB-RS232 serial converter, USB cable, N-m to BNC-f adapter, AC/DC power adapter, PES PMM Emission Suite Software, soft carrying case, operating manual, standard calibration certificate.

Optional accessories:

Options: 9010/RAV RMS-Avg detector, 9010-RMA Rack Mount Adapter for Rack 19"

Upgrades:

- | | |
|----------------|--|
| 7010/UP/01: | from 7010 to 7010 Opt. 01 (9 kHz to 1 GHz) |
| 7010/00/UP/01: | from 7010 Opt. 00 to 7010 Opt. 01 (9 kHz to 1 GHz) |
| 7010/02/UP/01: | from 7010 Opt. 02 to 7010 Opt. 01 (9 kHz to 1 GHz) |
| 7010/UP/03: | from 7010 to 7010 Opt. 03 (9 kHz to 3 GHz) |
| 7010/00/UP/03: | from 7010 Opt. 00 to 7010 Opt. 03 (9 kHz to 3 GHz) |
| 7010/01/UP/03: | from 7010 Opt. 01 to 7010 Opt. 03 (9 kHz to 3 GHz) |
| 7010/02/UP/03: | from 7010 Opt. 02 to 7010 Opt. 03 (9 kHz to 3 GHz) |

Related Products

Receivers

- 9010: EMI Receiver 10 Hz to 30 MHz
- 9010F: EMI Receiver 10 Hz to 30 MHz
- 9010/03P: EMI Receiver 10 Hz to 300 MHz
- 9010/30P: EMI Receiver 10 Hz to 3 GHz
- 9010/60P: EMI Receiver 10 Hz to 6 GHz
- 9030: EMI Receiver 30 MHz to 3 GHz
- 9060: EMI Receiver 30 MHz to 6 GHz
- 9180: EMI Receiver 6 GHz to 18 GHz

Antennas

- BC-01: Biconical Antenna 30 to 200 MHz
- DR-01: Double-ridged horn antenna 6 to 18 GHz
- LP-02: Log Periodic Antenna 200 MHz to 3 GHz
- LP-03: Log Periodic Antenna 800 MHz to 6 GHz
- VDH-01: Van der Hoofden test-head 20 kHz to 10 MHz
- TR-01: Antenna Tripod
- Antenna Set AS-02 (BC01+LP02+TR01)
- Antenna Set AS-03 (BC01+LP02+LP03+TR01)
- RA01: Rod Antenna 9 kHz to 30 MHz
- RA01-HV: Rod Antenna 150 kHz to 30 MHz
- RA01-MIL: Rod Antenna 9 kHz to 30 MHz

LISN&Probes

- L2-16B: single phase AMN, 16 A
- L3-32: 4 lines, 3-phase AMN, 32 A
- L3-64: 4 lines, 3-phase AMN, 63 A
- L3-64/690V: 4 lines, 3-phase AMN, 63 A
- L3-100: 4 lines, 3-phase AMN, 100 A
- L1-150M: single-path, 50 Ohm AMN, 150 A
- L1-150M1: single-path, 50 Ohm AMN, 150 A
- L1-500: single phase AMN, 500 A
- L3-500: 4 lines, 3-phase AMN, 500 A
- L2-D: Delta LISN for telecom, 2 A, 150 Ω
- SBRF4: RF Switching Box
- SHC-1/1000: Voltage probe, 1000 Vac, 35 dB
- SHC-2/1000: Voltage probe, 1000 Vac, 30 dB



A BRAND OF



an IEC Communications Company

Sales Office:
Via Leonardo da Vinci, 21/23
20090 Segrate (Milano) - ITALY
Phone: +39 02 2699871
Fax: +39 02 26998700

E-Mail: nardait.support@L-3com.com
Internet: www.narda-sts.it

Headquarter:
Via Benesse, 29/B
17035 Cisano sul Neva (SV) - ITALY
Phone: +39 0182 58641
Fax: +39 0182 586400